

Chad's Macbook	RJ-45 F	RJ-45 M	Cable	RJ-45 M	RJ-45 F	Mac Mini	Firewire 400 F	Firewire 400 M	Cable	Firewire 400 M	Firewire 400 F	Echo Audiofire 12										A&H GL4-32										
												Out 1	1/4 TRS F	1/4 TRS M	Channel 1	12 CH Snake										Channel 1	XLR M	XLR F	In 9			
												Out 2	1/4 TRS F	1/4 TRS M	Channel 2											Channel 2	XLR M	XLR F	In 10			
												Out 3	1/4 TRS F	1/4 TRS M	Channel 3											Channel 3	XLR M	XLR F	In 11			
												Out 4	1/4 TRS F	1/4 TRS M	Channel 4											Channel 4	XLR M	XLR F	In 12			
												Out 5	1/4 TRS F	1/4 TRS M	Channel 5											Channel 5	XLR M	XLR F	In 13			
												Out 6	1/4 TRS F	1/4 TRS M	Channel 6											Channel 6	XLR M	XLR F	In 14			
												Out 7	1/4 TRS F	1/4 TRS M	Channel 7											Channel 7	XLR M	XLR F	In 15			
												Out 8	1/4 TRS F	1/4 TRS M	Channel 8											Channel 8	XLR M	XLR F	In 16			
												Out 9	1/4 TRS F	1/4 TRS M	Channel 9											Channel 9	XLR M	XLR F	In 17			
												Out 10	1/4 TRS F	1/4 TRS M	Channel 10											Channel 10	XLR M	XLR F	In 18			
												God Mic	Shure SM 58	XLR M	XLR F	Cable										XLR M	XLR F	In 7				
Thomas	Countryman B6	TA 4 F	TA 4 M	Input	ULX Transmitter	559.775 MHz	ULX Reciever	Output	XLR M	XLR F	Cable										XLR M	XLR F	In 1									
Max	Countryman B6	TA 4 F	TA 4 M	Input	ULX Transmitter	566.850 MHz	ULX Reciever	Output	XLR M	XLR F	Cable										XLR M	XLR F	In 2									
Mandolin	Countryman B6	TA 4 F	TA 4 M	Input	ULX Transmitter	557.475 MHz	ULX Reciever	Output	XLR M	XLR F	Cable										XLR M	XLR F	In 3									
Acoustic Guitar	1/4 TRS F	1/4 TRS M	TA 4 F	TA 4 M	Input	ULX Transmitter	566.550 MHz	ULX Reciever	Output	XLR M	XLR F	Cable										XLR M	XLR F	In 4								
Violin	1/4 TRS F	1/4 TRS M	TA 4 F	TA 4 M	Input	ULX Transmitter	555.700 MHz	ULX Reciever	Output	XLR M	XLR F	Cable										XLR M	XLR F	In 5								
Spare 1	Countryman B6	TA 4 F	TA 4 M	Input	ULX Transmitter	557.675 MHz	ULX Reciever	Output	XLR M	XLR F	Cable										XLR M	XLR F	In 6									
Clear Com Headset	XLR-4 M	XLR-4 F	Clear Com Base Station	Ann Out	XLR F	XLR M	Barrel	XLR M	XLR F	Cable										XLR M	XLR F	In 8										
Denon 1800 F Remote	8 Pin Mini Din F	8 Pin Mini Din M	Cable	8 Pin Mini Din M	8 Pin Mini Din F	Denon 1800 F	Out L	RCA F	RCA M	Cable										XLR M	XLR F	In 19										
												Out R	RCA F	RCA M	Cable										XLR M	XLR F	In 20					

A&H GL4-32	Group 1	XLR M	XLR F										AUX Out 1	House Snake										AUX Send 1	XLR M	XLR F	Patch Cable	XLR M	XLR F	Amp 7	Booth Patchbay										XLR M	XLR F	In A	Crown Macrotech
	Group 2	XLR M	XLR F										AUX Out 2											AUX Send 2	XLR M	XLR F	Patch Cable	XLR M	XLR F	Amp 8											XLR M	XLR F	In B	Crown Macrotech
	Group 3	XLR M	XLR F										AUX Out 3											AUX Send 3	XLR M	XLR F	Patch Cable	XLR M	XLR F	Amp 9											XLR M	XLR F	In A	Crown Macrotech
	Group 4	XLR M	XLR F										AUX Out 4											AUX Send 4	XLR M	XLR F	Patch Cable	XLR M	XLR F	Amp 10											XLR M	XLR F	In B	Crown Macrotech
	Group 5	XLR M	XLR F										AUX Out 5											AUX Send 5	XLR M	XLR F	Patch Cable	XLR M	XLR F	Amp 11											XLR M	XLR F	In A	Crown Macrotech
	Group 6	XLR M	XLR F										AUX Out 6											AUX Send 6	XLR M	XLR F	Patch Cable	XLR M	XLR F	Amp 12											XLR M	XLR F	In B	1200
	Group 7	XLR M	XLR F										AUX Out 7											AUX Send 7	XLR M	XLR F	Patch Cable	XLR M	XLR F	Amp 13											XLR M	XLR F	In A	Crown Macrotech
	Group 8	XLR M	XLR F										AUX Out 8											AUX Send 8	XLR M	XLR F	Patch Cable	XLR M	XLR F	Amp 14											XLR M	XLR F	In B	Crown Macrotech
	Left	XLR M	Cable	XLR F	Channel 1 In	Ashly XR 4001	Channel 1 Low	XLR M	XLR F	Cable	XLR M	XLR F	Aux 9 Out											AUX Send 9	XLR M	XLR F	Patch Cable	XLR M	XLR F	Amp 17	Booth Patchbay										XLR M	XLR F	In A	Crown Macrotech
	Right	XLR M	XLR F	Cable										XLR M	XLR F	Shure PSM200 Transmitter	553.250 MHz	Shure PSM 200 Reciever																										
Aux 1	1/4 TRS F	1/4 TRS M	Cable	XLR F	XLR M	Left In	TC Electronic M3000	Left Out	XLR F	XLR M	Cable	XLR F	XLR M	Ch 21	A&H GL2-32																													
Aux 2	1/4 TRS F	1/4 TRS M	Cable	XLR F	XLR M	Left In	TC Electronic M3000	Right Out	XLR F	XLR M	Cable	XLR F	XLR M	Ch 22																														
						Left In		Right Out	XLR F	XLR M	Cable	XLR F	XLR M	Ch 24																														
Mono Out	XLR M	XLR F	Cable	XLR M	XLR F	Panel	Cable	XLR M	XLR F	Meyer M1-A	Out High	XLR M	XLR F	Cable										Binding Post	In 1	Crown ComTech 800																		
										Meyer M1-A	Out Low	XLR M	XLR F	Cable										Binding Post	In 2	Crown ComTech 800																		

Crown Macrotech 1200	OUT A	Binding Post	Banana Plug	House Wire	Amp Room Patchbay	Amp 7 Out	NL4-MP	NL4-MC	Patch Cable	NL4-MC	NL4-MP	LS 11	Amp Room Patchbay	House Wire	LS Plate 11	NL4-MP	NL4-MC	Cable	NL4-MC	NL4-MP	EAW JFX-290	North East Ring				
Crown Macrotech 1200	OUT B	Binding Post	Banana Plug			Amp 8 Out	NL4-MP	NL4-MC	Patch Cable	NL4-MC	NL4-MP	LS 46			LS Plate 46	NL4-MP	NL4-MC	Cable	NL4-MC	NL4-MP	EAW JFX-290	South East Ring				
Crown Macrotech 1200	OUT A	Binding Post	Banana Plug			Amp 9 Out	NL4-MP	NL4-MC	Patch Cable	NL4-MC	NL4-MP	LS 43			LS Plate 43	NL4-MP	NL4-MC	Cable	NL4-MC	NL4-MP	EAW JFX-290	South West Ring				
Crown Macrotech 1200	OUT B	Binding Post	Banana Plug			Amp 10 Out	NL4-MP	NL4-MC	Patch Cable	NL4-MC	NL4-MP	LS 13			LS Plate 13	NL4-MP	NL4-MC	Cable	NL4-MC	NL4-MP	EAW JFX-290	North West Ring				
Crown Macrotech 1200	OUT A	Binding Post	Banana Plug			Amp 11 Out	NL4-MP	NL4-MC	Patch Cable	NL4-MC	NL4-MP	LS 5			LS Plate 5	NL4-MP	NL4-MC	Cable	NL4-MC	NL4-MP	EAW JF- 80	North East Corridor				
Crown Macrotech 1200	OUT B	Binding Post	Banana Plug			Amp 12 Out	NL4-MP	NL4-MC	Patch Cable	NL4-MC	NL4-MP	LS 3			LS Plate 3	NL4-MP	NL4-MC	Cable	NL4-MC	NL4-MP	EAW JF- 80	South East Corridor				
Crown Macrotech 1200	OUT A	Binding Post	Banana Plug			Amp 13 Out	NL4-MP	NL4-MC	Patch Cable	NL4-MC	NL4-MP	LS 8			LS Plate 8	NL4-MP	NL4-MC	Cable	NL4-MC	NL4-MP	EAW JF- 80	South West Corridor				
Crown Macrotech 1200	OUT B	Binding Post	Banana Plug			Amp 14 Out	NL4-MP	NL4-MC	Patch Cable	NL4-MC	NL4-MP	LS 7			LS Plate 7	NL4-MP	NL4-MC	Cable	NL4-MC	NL4-MP	EAW JF- 80	North West Corridor				
Crown Macrotech 2400	OUT A	Binding Post	Banana Plug			Amp 17 Out	NL4-MP	NL4-MC	Patch Cable	NL4-MC	NL4-MP	LS 4			LS Plate 4	NL4-MP	NL4-MC	Cable	NL4-MC	NL4-MP	JBL MP48S	East Corridor				
Shure PSM 200 Reciever	1/8 TRS F	1/8 TRS M	Cable												RCA Male	RCA F	Listen Tech LR600	Trash Can								
Crown Microtech 800	Out 1	Screw Posts	House Cable										Panel	NL4-MP (4 Conductor)	NL4-MC	Cable	NL4-MC	NL4-MXX	Barrel	NL4-MXX	NL4-MC	Y Cable	NL4-MC	NL4-MP	Meyer UPA-1	Array HL
	Out 2	Screw Posts	House Cable										Panel	NL4-MP (4 Conductor)	NL4-MC	Cable	NL4-MC	NL4-MXX	Barrel	NL4-MXX	NL4-MC	Y Cable	NL4-MC	NL4-MP	Meyer UPA-1	Array HR